

AC Soluble Elastin PF Sample Formulations

Code: 20595PF
INCI Name: Hydrolyzed Elastin
CAS #: 91080-18-1
EINECS #: 293-509-4

Sample Finished Formulation Guidelines

Sea Salt Body Scrub
FNBB01-71 – Sea Salt Body Scrub

Chest and Neck Firmer
CTNC11-007 – Chest and Neck Firmer



FNBB01-71 Sea Salt Body Scrub Sample Formulation

info@activeconceptsllc.com • +1 (704)-276-7100 • Fax: +1 (704)-276-7101

Ingredient	Trade Name/Vendor	%
Phase I		
Glycerin	Glycerin	QS
Decaglyceryl Dipalmitate	Polyaldo 10-2-P/Lonza	10.00
Phase II		
Polyethylene	Asensa SC 201/Honeywell	5.00
Oxidized Polyethylene	Asensa SC 233/Honeywell	5.00
Sea Salt	Coarse Dead Sea Salt/International Sourcing	20.00
Propylene Glycol & Water & Malic Acid & Glycolic Acid & Lactic Acid & Pyrus Malus (Apple) Fruit Extract & Citric Acid	ABS Apple AHA/Active Concepts, LLC	10.00
Water & Butylene Glycol & Fucus Vesiculosos Extract	ABS Bladderwrack Extract/Active Concepts, LLC	5.00
Soluble Collagen	AC Marine Collagen/Active Concepts, LLC	1.00
Hydrolyzed Elastin	AC Marine Elastin/Active Concepts, LLC	1.00
Potassium Cocyl Hydrolyzed Collagen	AC Foaming Collagen/Active Concepts, LLC	1.00
Lactobacillus Bulgaricus Ferment Filtrate	ACB Yogurt Dermal Respiratory Factor/Active Concepts, LLC	5.00
Lactobacillus/Punica Granatum Fruit Ferment Extract	ACB Modified Pomegranate Enzyme/Active Concepts, LLC	2.50
Water & Pyrus Communis (Pear) Fruit Extract	ABS Pear Fruit Extract/Active Concepts, LLC	5.00
Water & Butylene Glycol & Sea Silk Extract	ABS Sea Silk Extract/Active Concepts, LLC	1.00
Rose Quartz	AC Powdered Rose Quartz/Active Concepts, LLC	0.50
Propylene Glycol (and) Diazolidinyl Urea (and) Methylparaben (and) Propylparaben	Germaben II/ISP	1.00

Manufacturing Instructions:

Phase I: Charge Glycerin and Polyaldo 10-2-P into main beaker and begin sweep mixing. Heat to 70°C.

Phase II: Once Phase I has been blended remove heat. At 60°C, begin adding Phase II ingredients. Fill into appropriate container once complete.

Information contained in this technical literature is believed to be accurate and is offered in good faith for the benefit of the customer. The company, however, cannot assume any liability or risk involved in the use of its chemical products since the conditions of use are beyond our control. Statements concerning the possible use of our products are not intended as recommendations to use our products in the infringement of any patent. We make no warranty of any kind, expressed or implied, other than that the material conforms to the applicable standard specification.



Tomorrow's Vision... Today!

Chest and Neck Firmer Formulation Code: CTNC11-007

Ingredient	Trade Name/Vendor	%
Phase I		
Water	Water	QS
Sodium Phytate	Dermofeel PA-3/Dr. Straetmans	0.20
Populus Tremuloides (Aspen) Bark Extract	PhytoCide Aspen Bark Extract Powder/Active Micro Technologies	2.00
Water (and) Algae Extract	AC Alg-Moist EAU/Active Concepts	5.00
Phase II		
Euterpe Oleracea Oil	AC Acai Oil/Active Concepts	1.00
Ethylhexyl Palmitate (and) Silica Dimethyl Silylate (and) Butylene Glycol (and) Gamma Aminobutyric Acid (and) Caprylyl Glycol (and) Phenoxyethanol (and) Hexylene Glycol (and) Sodium Hyaluronate	AC NanoVector Plump GABA HYA/Active Concepts	3.00
Rubus Chamaemorus Seed Oil	AC Cloudberry Seed Oil/Active Concepts	1.00
PPG-26 Buteth-26/PEG-40 Hydrogenated Castor Oil	Solubilisant LRI/LCW	4.00
Polysorbate 20	Ritabate 20/Rita Corp.	4.00
Phase III		
Water (and) Saccharomyces Lysate Extract	AC Dermal Respiratory Factor Advanced/Active Concepts	1.00
Water (and) Prunus Amygdalus Dulcis (Sweet Almond) Seed Extract	AC DermaPeptide Lifting/Active Concepts	4.00
Lactobacillus/Eriodictyon Californicum Ferment Extract	ACB Yerba Santa Glycoprotein/Active Concepts	5.00
Griffonia Simplicifolia Seed Extract	AC Griffonia Lysate Advanced/Active Concepts	1.00
Hydrolyzed Keratin	AC Elastin/Active Concepts	1.50
Lactobacillus Ferment	Leucidal Liquid SF/Active Micro Technologies	2.00
Fragrance	Cassis Leaf S6-31041/Premier Specialties	0.20

Process Instructions:

- Phase I:** Add water into main beaker and begin propeller mixing. A vortex should form. Add Dermofeel PA-3. Sift in PhytoCide Aspen Bark Extract Powder. Add AC Alg-Moist EAU.
- Phase II:** In a separate container, blend ingredients and heat to 60°C. Once mixture is fully blended, add to Phase I.
- Phase III:** Add each individually.